



Product Instructions

Printed Matter No. 6159923680

Date: 2026-06 Issue No. 02

Nutrunner

Valid from Serial No. A-00001-202601 to Z-99999-203612

Model:

CP6613

CP6626

CP6641

CP6681



	⚠ WARNING
	Read all safety warnings and instructions Failure to follow the safety warnings and instructions may result in electric shock, fire and/or serious injury. Save all warnings and instructions for future reference

Table of Contents

Installation..... 3

 Assembling the reaction bar..... 3

 Assembling the output drive socket..... 3

 Connecting the Inlet Air Nut 3

 Connecting the tool with FRL 4


Operation..... 6

 Operating the tool..... 6


 Using the reaction bar 7

Installation


Assembling the reaction bar



Assembling the output drive socket




Connecting the Inlet Air Nut




Connecting the tool with FRL


1.




2.




3.



4.




5.




Operation

Operating the tool


1.




2.




3.




4.



5.



Using the reaction bar



ABOUT CHICAGO PNEUMATIC



At Chicago Pneumatic, we have a passion for performance and long-lasting partnerships with our customers in industrial applications, construction, infrastructure and maintenance. Since 1901, we have been committed to reliability based on technology and trust.

TO LEARN MORE, VISIT WWW.CP.COM

